FLEXI-SEAL
INSTALLATION INSTRUCTIONS

DO NOT USE IN CONJUNCTION WITH **ACETOXY** BASED SILICONE SEALANT.

- Ensure the application surface is clean and free from dust.

- Carefully peel the protective film from the Flexi-Seal adhesive.

- Firmly apply the adhesive section of the seal to the application surface as per the diagrams opposite, ensuring there are no wrinkles or bumbs.

- **DO NOT STRETCH THE SEAL WHEN APPLYING.**

- Install the shower tray/bath into situ as normal.

- Fit tiles or panelling over the top of the Flexi-Seal as per the diagram opposite.